







Available in “Headunit” HU\_NBT, “Headunit” HU\_NBT\_EVO

**Shut off iDrive system when driver door is opened**

Enable/disable the automatic shut-off of the iDrive system when the driver door is opened.

Values:





Values:

- Active
- Not active

Available in “Body Domain Controller” BDC\_01





- Display pressure only

Available in “Instrument Cluster” KOMBI\_I01\_F56“In.2 (M) -0. (e) 0.2 (r”) 0.2 ( K9A7 BT 50 0 0





### **Number of washing operations for headlight cleaning**

The number of washing operations as of which the headlight cleaning is turned on.

- Active
- Not active

- 20%
- 30%
- 40%
- 50%
- 60%
- 70%
- 80%
- 90%
- 100%

Available in “Body Domain Controller” BDC\_01

Enable/disable the unfolding of the mirrors when using the Comfort Opening.

Values:

-





- 33 °C
- 34 °C
- 35 °C

Available in “Body Domain Controller” BDC\_01

Values:

Available in “Body Domain Controller” BDC\_01

- 43 °C
- 44 °C
- 45 °C
- 46 °C

Available in “Body Domain Controller” BDC\_01

### **Seat heating/cooling setting memory**

The memory duration of the seat heating/cooling settings.

Values:

- 15 minutes
- 24 hours
- Do not save
- Unlimited

Available in “Seat Module Passenger” CBFS\_PLX\_1, “Seat Module Driver” CFAS\_PLX\_1

Seatbelt reminder

### **Initial seat belt reminder after start**



## **Seat belt reminder speed**

Speed as of which th seat belt reminder is activated.

Values:

-

Available in “Body Domain Controller” BDC\_01





Available in “Headunit” HU\_NBT, “Headunit” HU\_NBT\_EVO

Voltage monitoring

**Adaptive brake light cold monitoring**

Values:

- Active
-

- Not active

Available in “Body Domain Controller” BDC\_01

**Daytime running lights cold monitoring**



- Not active















The number of wipe cycles after front washing

Values:

○

